

# The Party Corner

19 E. Newman Springs Rd. Shrewsbury, N.J. 07702  
732-741-0040 Fax: 732-747-1589

[www.partycorner.com](http://www.partycorner.com)

**Email: partycorner@msn.com**

*"So many reasons to party...but only one place to shop!"*

Since 1969, serving all your party and event rental needs.

## OPERATING INSTRUCTIONS BEVERAGE FOUNTAINS

Beverage fountains are designed to circulate clear liquids. Use of beverages with pulp, seeds, fruit, rinds, etc. will restrict the flow of beverage and may give unsatisfactory results. Use of ice cream or other foamy punches may also restrict the flow of the beverage.

- 1) Pour approximately 2 quarts of beverage into lower reservoir and turn switch on. If beverage does not circulate within one minute, turn switch off for 10 seconds. Repeat this procedure until beverage flows freely. If this procedure fails, pour beverage in top reservoir with the switch in ON position until pump is activated.

DO NOT run fountain dry. DO NOT immerse base of fountain in water.

Cleaning: Empty out remaining beverage and fill lower reservoir with 2 gallons of warm water and let circulate for 5 minutes. Empty unit and repeat.

Do not use scouring pads of any type. Do not take apart.

Helpful hints: To chill beverage, use chunks of ice in bowl, ice cubes in plastic bag. Precool beverage whenever possible to at least 36 degrees F.

