

The Party Corner

19 E. Newman Springs Rd. Shrewsbury, N.J. 07702
732-741-0040 Fax: 732-747-1589

www.partycorner.com

Email: partycorner@msn.com

"So many reasons to party...but only one place to shop!"

Since 1969, serving all your party and event rental needs.

OPERATING INSTRUCTIONS TABLE TOP HOT DOG CART

Place on a level surface. Connect power cord to a suitable outlet of correct voltage.

- 1) Fill bottom of well with hot water until it contacts the bottom of the food pan. If perforated pan is used, do not allow the water to enter the pan.
- 2) Place holding pan into well, (any combination of pans to completely cover the well.)
- 3) Preheat on high for 30 minutes. (Water temperature should be at least 180 degrees F.)
- 4) Place food product in pans and allow it to heat until internal temperature is at least 150 degrees F. (When cooking hotdogs, fill non perforated pans approximately half full of hot water before adding hotdogs.)
- 5) Adjust temperature setting to hold product at 150 degrees F. serving temperature.
- 6) Keep lids in place to help maintain temperature.

